DAEWOO

Service Manual

Digital Home Cinema System

Model : DHC-XD350

DAEWOO ELECTRONICS CO., LTD.

DIGITAL HOME CINEMA SYSTEM

DHC-XD350

Contents

1. SAFETY PRECAUTIONS.....3/4

2. SPECIFICATIONS.....5

3. LOCATION OF USERS CONTROLS.....6/8
- -. FRONT PANEL.
- -. REAR PANEL.
- -. DISPLAY.
- -. REMOTE CONTROLLER.

4. CONNECTING TO EQUIPMENT......9/11
- -. CONNECTING TO TV.
- -. CONNECTING TO AUDIO & VIDEO.
- -. CONNECTING TO SPEAKER.
- -. CONNECTING TO RECORDING EQUIPMENT.

5. TROUBLE SHOOTING GUIDE......12/19

6. DVD PROGRAM DOWNLOAD METHOD......20

7. WAVEFORMS OF MAJOR CHECK POINT......21/22
- -. AUDIO OUT SIGNAL WAVEFORM.
- -. DAC OUTPUT SIGNAL WAVEFORM.
- -. OPTICAL OUTPUT AUDIO DATA SIGNALFORM.
- -. L/R CLOCK DATA WAVEFORM DURING NORMAL PLAY.
- -. SERIAL DATA OUTPUT WAVEFORM DURING NORMAL PLAY.
- -. Cr OUTPUT DATA WAVEFORM IN COMPONENT OUTPUT.
- -. Cb OUTPUT DATA WAVEFORM IN COMPONENT OUTPUT.
- -. Y OUTPUT DATA WAVEFORM IN COMPONENT OUTPUT.

8. INTERNAL BLOCK DIAGRAM OF ICs......23/30

9. BLOCK DIAGRAM.....31/33

10. WIRING DIAGRAM.....34

11. SCHEMATIC DIAGRAM......35/41
- - AMP SCHEMATIC DIAGRAM.
- -. FRONT SCHEMATIC DIAGRAM.
- -. DDX SCHEMATIC DIAGRAM.
- -. IO SCHEMATIC DIAGRAM.
- -. MPEG DECODER SCHEMATIC DIAGRAM.
- -. MPEG OUTPUT SCHEMATIC DIAGRAM.
- -. REGULATOR SCHEMATIC DIAGRAM.

12. PRINTED CIRCUIT DIAGRAM......42/48
- -. FRONT PCB.
  - 1) TOP VIEW.
  - 2) BOTTOM VIEW.
- -. IO PCB.
  - 1) TOP VIEW.
  - 2) BOTTOM VIEW.
- -. MPEG PCB.
  - 1) TOP VIEW.
  - 2) BOTTOM VIEW.
- -. MAIN PCB.
  - 1) TOP VIEW.
  - 2) BOTTOM VIEW.
- -. REGULATOR PCB.

13. MECHANISM......49

14. EXPLODED VIEW......50/52
- -. MECHANICAL EXPLODED VIEW
- -. MECHANICAL PARTS LIST
- -. DISASSEMBLY VIEW

15. ELECTRICAL PARTS LIST......53/57
- -. ELECTRICAL PARTS LIST

1. Safety Precautions

WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

CAUTION
RISK OF ELECTRIC SHOCKS
DO NOT OPEN

CAUTION : TO REDUCE THE RISK IF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

THIS SYMBOL IS INTENDED TO ALERT THE USER TO THE PRESENCE OF UNINSULTED "DANGEROUS VOLTAGE" WITHIN THE PRODUCT'S ENCLOSURE THAT MAY BE SUFFICIENT MAGNITUDE TO CONSTITUTE A RISK OF ELECTRIC SHOCK TO PERSONS.

THIS SYMBOL IS INTENDED TO ALERT THE USER TO THE PRESENCE OF IMPORTANT OPERATING AND MAINTENANCE (SERVICING) INSTRUCTIONS IN THE LITERATURE ACCOMPANYING THE APPLIANCE.

CAUTION

TO PREVENT ELECTRIC SHOCK, DO NOT USE THIS POLARIZED AC PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

LASER SAFETY

THIS UNIT EMPLOYS A LASER. ONLY QUALIFIED SERVICE PERSONNEL SHOULD REMOVE THE COVER OR ATTEMPT TO SERVICE THIS DEVICE DUE TO POSSIBLE EYE INJURY.

CAUTION : USE OF ANY CONTROLS, ADJUSTMENTS, OR PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

CAUTION : TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

ATTENTION : POUR EVITER LES CHOCS ELECTRIQUES, INTRODUIRE LA LAME LA PLUS LARGE DE LA FICHE DANS LA BORNE CORRESPONDANTE DE LA PRISE ET POUSSER JUSQU'AU FOND.

Important Safety Instructions

- All the safety and operating instructions should be read before the appliance is operated.
- The safety and operating instructions should be retained for future reference.
- All warnings on the appliance and in the operating instructions should be adhered to.
- All operating and use instructions should be followed.

1. Water and Moisture - The appliance should not be used near water - for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, and the like.

PORTABLE CART

Figure 2

2. Carts and Stands - The appliance should be used only with a cart or stand that is recommended by th manufacturer.
3. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.
4. Wall or Ceiling Mounting - The appliance should be mounted to a wall or ceiling only as recommended by the manufacturer.
5. Ventilation - The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or, placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.
6. Heat - The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
7. Power Sources - The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
8. Grounding or Polarization - The precautions that should be taken so that the grounding or polarization means of an appliance is not defeated.
9. Power - Cord Protection - Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.
10. Protective Attachment Plug - If the appliance is equipped with an attachment plug having overload protection. This is a safety feature. See Instruction Manual for replacement or resetting of protective device. If replacement of the plug is required, be sure the service technician has used a replacement plug specified by the manufacturer that has the same overload protection as the original plug.
11. Cleaning - The appliance should be cleaned only as recommended by the manufacturer.
12. Power Lines - An outdoor antenna should be located away from power lines.

1. Safety Precautions

13.Outdoor Antenna Grounding - If an outside antenna is connected to the receiver be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna-dis charge unit, size of grounding conductors,location of antenna-discharge unit, connection to grounding electrodes and requirements for the grounding electrode. See Figure 1.


EXAMPLE OF ANTENNA GROUNDING
ANTENNA LEAD IN WIRE
GROUND CLAMP
ANTENNA DISCHARGE UNIT (NEC SECTION 810-20)
GROUNDING CONDUCTORS (NEC SECTION 810-21)
ELECTRIC SERVICE EQUIPMENT
GROUND CLAMPS
POWER SERVICE GROUNDING ELECTRODE SYSTEM (NEC ART 250 PART H)
NEC - NATIONAL ELECTRICAL CODE

14.Non-use Periods - The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.

15.Object and Liquid Entry - Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.

16.Damage Requiring Service - The appliance should be serviced by qualified service personnel when:

a) The power-supply cord or the plug has been damaged; or

b) Objects have fallen, or liquid has been spilled into the appliance; or

c) The appliance has been exposed to rain; or

d) The appliance does not appear to operate normally or exhibits a marked change in performance; or

e) The appliance has been dropped, or the enclosure damaged.

17.Servicing - The user should not attempt to service the appliance beyond that described in the operating instructions. All other servicing should be referred to qualified service personnel.

2. Specifications

DHC-XD350

Power supply Voltage (Option)	AC 110V or 120V or 127V or 220V or 230V or 240V (50/60Hz)	**Power consumption**	Standby 2Watt Operating 80Watt
		Dimensions (W x D x H) / Weight	360 x 380 x 70mm/ 6.7 kg

Front Amp. Section

POWER OUTPUT at 1% THD(DIN)	At 1KHz, 8 ohms	30W
THD(Total Harmonic Distortion)	At 1KHz, 1W	0.1%
Input Sen. / Impedance @ 1KHz, 47K ohms	VIDEO, TV/AUX	200mV ¡ 30mV/47K
Output Level/Impedance @ 1KHz	Video Rec	200mV ¡ 30mV/2.2K
Frequency Response(Analogue)	at 1W : TV/AUX -3dB	20Hz~20KHz
S/N Ratio IHF-A Weighted	TV/AUX	70dB
Subwoofer Turnover Frequency		¡ ´120Hz
Channel Separation	TV/AUX:1KHz	65dB
Crosstalk	VIDEO -->TV/AUX	65dB
	TV/AUX--> VIDEO	65dB

Center Amp Section

POWER OUTPUT at 1% THD(DIN)	At 1KHz, 8 ohms	30W
TOTAL HARMONIC DISTORTION	At 1KHz, 1W	0.1%
S/N RATIO, IHF-A FILTER	10W	70dB
FRE. RESPONSE LARGE	1W	20Hz~20KHz
DOLBY MODE SMALL	1W	135Hz~18KHz

Rear Amp Section

POWER OUTPUT 1% THD(DIN)		At 1KHz, 8 ohms	30W
TOTAL HARMONIC DISTORTION		At 1KHz, 1W	0.1%
S/N RATIO	DOLBY	10W	70dB
FREQUENCY RESPONSE	LARGE	1W	20Hz~20KHz
(Dolby Digital)	SMALL	1W	135Hz~18KHz

Subwoofer Section

POWER OUTPUT at 10% THD	At 100Hz, 8 ohms	30W
FREQUENCY RESPONSE	1W	20Hz~150Hz
S/N RATIO, IHF-A Weight		60dB

Video Section

Input Sen./Impedance	Composite Video(Video)	1Vp-p/75 ohm	¡ 0.5 dB
Output Level/Impedance	Composite 75 ohm	1Vp-p/75 ohm	¡ 0.5 dB
	S-Video(Y/C) 75 ohm(DVD only)	1Vp-p/ 0.286Vp-p	¡ 0.5 dB
	Component Out(Y/ Cb/ Cr):Option	1Vp-p/0.7Vp-p/0.7Vp-p	¡ 0.5 dB
Frequency Response	Ref 500KHz		5Hz~5.7MHz
Crosstalk	@1MHz	45dB	40dB
S/N Ratio	DVD	60dB	

FM Tuner Section (FM ANT Impedance : 75 ohms)

Tuning Range	USA Version	87.5~108.0MHz
	Europe Version	87.5~108.0MHz
Scanning Frequency Interval	USA Version	100KHz
	Europe Version	50KHz
Usable Sensitivity, 75 ohms	S/N=30dB,USA Version	2uV(17.2dBf)
	S/N=26dB,Europe Version	3uV(20.8dBf)
S/N Ratio @1mV IHF-A FILTER	Mono USA Version	70dB
	Mono Europe Version	70dB
	Stereo USA Version	65dB
	Stereo Europe Version	63dB

DHC-XD350



Front panel

1. POWER ON/OFF switch
2. DVD/VIDEO CD/MP3 CD/audio CD disc tray
3. Remote Control Sensor
4. Display
5. MASTER VOLUME control
6. STANDBY indicator
7. STANDBY/ON button
8. OPEN/CLOSE (⏏) button
9. PLAY (▶) button
10. STOP (■) button
11. PRE (⏮) button
12. NEXT (⏭) button
13. FUNCTION button
14. PHONES jack

3. Location of Users Controls

DHC-XD350

-. Rear Panel



1. COMPONENT VIDEO OUTPUT Y/Cb/Cr jacks or SCART jack(Optional)
2. S VIDEO MONITOR OUT jack
3. AUX IN jacks
4. VIDEO (IN) jack
5. VIDEO (OUT) jack
6. DIGITAL OUTPUT jack
7. CENTER SPEAKER connector
8. FRONT SPEAKER connector
9. REAR SPEAKER connector
10. Power cord
11. FM ANTENNA connector
12. SUBWOOFER output jack
13. MONITOR OUT jack
14. WOOFER connector

-. Display



1. SPEAKER CONFIGURATION indicator
2. TITLE indicator
3. PRESET indicator
4. CHAPTER indicator
5. TRACK indicator
6. FILE indicator
7. SUB indicator
8. DIR indicator
9. TOTAL indicator
10. REMAIN indicator
11. SLEEP indicator
12. SOURCE indicator
13. PROLOGIC indicator
14. DOLBY DIGITAL indicator
15. PLAY indicator
16. PAUSE indicator
17. DTS indicator
18. DSP indicator
19. PCM indicator
20. PBC(Playback Control) indicator
21. RDS indicator
22. TA/TP indicator
23. STEREO indicator
24. MUTE indicator
25. RANDOM indicator
26. REPEAT indicator
27. INTRO indicator

3. Location of Users Controls

-. Remote Controller

DHC-XD350



1. STANDBY/ON button
2. OPEN/CLOSE button
3. MUTE button
4. INPUT SELECTOR: DVD button
5. INPUT SELECTOR: TUNER button
6. INPUT SELECTOR: VIDEO, TV/AUX button
7. FAST REVERSE(FR) (◀◀) button
8. SKIP PREV (I◀◀) button
9. SPEAKER SETUP button
10. CH LEVEL button
11. PLAY (▶) button
12. STOP(■) button
13. MENU/RETURN button
14. PAUSE/STEP button
15. Number buttons
16. DISPLAY/FM MODE button
17. TEST TONE button
18. SUBTITLE button
19. SLOW button
20. A-B REPEAT button
21. ANGLE button
22. RANDOM button
23. DIGEST/RDS MODE button
24. MPX/PTY SEARCH button
25. SLEEP button
26. FAST FORWARD(FF) (▶▶) button
27. SKIP NEXT (▶▶I) button
28. MOVE ▲/▼/◀/▶/ENTER buttons
29. SURROUND MODE button
30. TITLE button
31. VOLUME ▲/▼ buttons
32. SET-UP button
33. GO TO/AUTO MEMORY button
34. DELAY TIME button
35. AUDIO button
36. ZOOM button
37. REPEAT button
38. PBC button

4. Connecting to Equipment

-. Connecting to TV

DHC-XD350

- If the TV or monitor is equipped with an S video input, make the S video connection in addition to the normal video connection. The S video connection will provide higher quality picture playback.



- 21-Pin SCART Cable(not included) to 21-pin SCART input terminal on TV
- SCART Specification : Composite and Component Video output(DVD, Video) Audio L/R Output(DVD only)

(Yellow)
(Red)
(White)
Both the S video and video connections are necessary, otherwise the picture from equipment to be connected on the next page may not be output to the TV.
TV / Monitor
L (White)
To audio outputs
R (Red)
Stereo audio connection cable
S video connection cable
Video connection cable
(Yellow)
To video input
To S video input

4. Connecting to Equipment

-. Connecting to AUDIO & VIDEO

DHC-XD350



4. Connecting to Equipment

-. Connecting to Speaker

DHC-XD350

◆ **Before connecting**

- Refer also to the instruction manuals of the speakers.
- This machine is designed to reproduce optimum sound quality when speakers with the specified impedance below are connected.Please check the following information and choose speakers with appropriate impedance for the connections.

Front speakers / Center speaker / Surround Speakers : 8 ohms min. per speaker
Subwoofer speaker : 8 ohm min

- To prevent damage to circuits, never short-circuit the positive (+) and negative (-) speaker wires.
- Do not connect the speaker cable to the L and R connectors at the same time and do not connect more than one speaker to the same speaker connectors.



-. Connecting to Recording Equipment



5. Trouble Shooting Guide

-. Audio Part

DHC-XD350

1. Basic Operating



2. Front Micom Circuit



5. Trouble Shooting Guide

-. Front Circuit

DHC-XD350



5. Trouble Shooting Guide

-. Audio Part

DHC-XD350

1. DVD Abnormal(w/o DSP)


AUDIO Abnormal
Check if the WC701 is OK.
No
Reconnect it
Yes
Check if the CW507 waveform is OK.
No
Refer to Regulator circuit.
Yes
Check if the CW503 PIN 1 to 7 waveform are OK.
No
Refer to MPEG Decoder circuit IC501.
Yes
Check if the CW203 PIN 1 to 7 waveform are OK.
No
Refer to CN203
Yes
Check if the IC211 PIN 4, 7, 9, 12 waveform is OK.
No
Refer to MUX circuit IC211.
Yes
Check if the IC212 PIN 4, 7, 9 waveform is OK.
No
Refer to MUX circuit IC212.
Yes
1
1
Check if the IC202 PIN 23,24, 27, 28, 29, 30, 33, 34 and IC201 PIN 27, 28, 33, 34 waveform is OK.
No
Check if the IC201, 202 PIN 14 is OK.
No
Check POWER circuit. Check OSC circuit XC201.
Yes
Check if the IC201, IC202 PIN 35 is High?
No
Check MICOM Control circuit.
Yes
Refer to STA304A.
Yes
Check if the J801 waveform is OK.
No
Check if the IC801, IC802, IC803 PIN 4, 7, 12, 15 waveform are OK.
No
Refer to POWER circuit.
Yes
Check if the IC801, IC802, IC803 PIN 27 is High.
No
Check short parretn.
Yes
Refer to Digital Amp.
Yes
OK

5. Trouble Shooting Guide

-. Audio Part

DHC-XD350

2. DVD Abnormal(with DSP)


AUDIO Abnormal
Check if the WC701 is OK.
No
Reconnect it
Yes
Check if the CW507 waveform is OK.
No
Refer to Regulator circuit. Refer to IC302, IC309.
Yes
Check if the CW503 PIN 3 waveform is OK.
No
Refer to MPEG Decoder circuit IC501.
Yes
Check if the CW304 PIN 20 waveform is OK.
No
Check if the IC304 PIN 5 waveform is OK.
No
Refer to Main PCB 12.288MHz.
Yes
Check if the IC301 PIN 39, 40, 41 waveform are OK.
No
Refer to Regulator circuit IC302, IC309 Refer to Reset circuit
Yes
Check if the IC304 PIN 28 waveform is OK.
No
Yes
Check if the CW204 PIN 8, 9, 10, waveform are OK.
No
Refer to connector
Refer to CN203
Check Micom interface line.
Yes
1
1
Check if the IC202 PIN 23,24, 27, 28, 29, 30, 33, 34 and IC201 PIN 27, 28, 33, 34 waveform is OK.
No
Check if the IC201, 202 PIN 14 is OK.
No
Check POWER circuit. Check OSC circuit XC201.
Yes
Check if the IC201, IC202 PIN 35 is High?
No
Check MICOM Control circuit.
Yes
Refer to STA304A.
Yes
Check if the J801 waveform is OK.
No
Check if the IC801, IC802, IC803 PIN 4, 7, 12, 15 waveform are OK.
No
Refer to POWER circuit.
Yes
Check if the IC801, IC802, IC803 PIN 27 is High.
No
Yes
Yes
OK
Refer to Digital Amp.
Check short parretn.

5. Trouble Shooting Guide

-. Audio Part

DHC-XD350







5. Trouble Shooting Guide

-. Audio Part

DHC-XD350









5. Trouble Shooting Guide

-. Audio Part

DHC-XD350







5. Trouble Shooting Guide

-. Audio Part

DHC-XD350





6. DVD Program Download Method

DHC-XD350

INSERT THE UPDATE DISC INTO THE DISC TRAY, THEN THE DVD RECEIVER READS THE DISC AND UPDATE THE FIRMWAFE ITSELF AS FOLLOWINGS.

@ INSERT THE UPDATE DISC. "Bank 30. Rom"

NO	STATUS	VFD	MONITOR	SET CONDITION
1	STARTING UPDATE	LOADING	LOADING	DOOR CLOSE
2	DETECT THE UPDATE DISC	STOP MP3	BANK30. ROM	DOOR CLOSE
3	READ THE DISC	STOP MP3	WRITING	DOOR CLOSE
4	COMPLETED THE READ	STOP MP3	DONE	DOOR CLOSE
5	COMPLETED THE UPDATE	STOP MP3		DOOR OPEN 1)
6	END	DISPLAY	LOADING	DOOR CLOSE : 1) 4 SEC

NOTE :

1) AFTER DOOR OPEN, EJECT THE UPDATE DISC.
2) AFTER COMPLETED, POWER OUT AND IN AGAIN.

CAUTION :

WHILE DOOR OPEN, IF CD DOOR IS CLOSED BY TOUCH, OR POWER BUTTON IS PRESSED THEN FLASH MEMORY WILL BE ERASED.

7. Waveforms of Major Check Method

DHC-XD350

※ TEST POINT : DVD TEST DISC "MDVD-W111 TRACK2 COLOR BAR"

-. Audio Out Signal Waveform



-. DAC Output Signal Waveform



-. Optical Output Audio Data Signal waveform



-. L/R Clock Data Waveform During Normal Play



-. Serial Data Output Waveform During Normal Play



7. Waveforms of Major Check Method

DHC-XD350

※ TEST POINT : DVD TEST DISC " MDVD-W111 TRACK2 COLOR BAR"

-. Cr Output Data Waveform in Component Output





-. Cb Output Data Waveform in Component Output





-. Y Output Data Waveform in Component Output





8. Internal Block Diagram of ICs

DHC-XD350

• AK-4112A





Serial Control Mode



Parallel Control Mode

8. Internal Block Diagram of ICs

DHC-XD350

• AME1117



• STA304A



8. Internal Block Diagram of ICs

DHC-XD350

• CS4228A




Serial Audio Data In 3 SDIN3 1
Serial Audio Data In 2 SDIN2 2
Serial Audio Data In 1 SDIN1 3
Serial Audio Data Out SDOUT 4
Serial Clock SCLK 5
Left/Right Clock LRCK 6
Digital Ground DGND 7
Digital Power VD 8
Digital Interface Power VL 9
Master Clock MCLK 10
SCL/CCLK SCL/CCLK 11
SDA/CDIN SDA/CDIN 12
AD0/CS AD0/CS 13
Reset RST 14
28 SUB Analog Out #6,Subwoofer
27 CENTER Analog Out #5, Center
26 SR Analog Out #4, Surround Right
25 SL Analog Out #3, Surround Left
24 FR Analog Out #2, Front Right
23 FL Analog Out #1, Front Left
22 AGND Analog Ground
21 VA Analog Power
20 AINL+ Left Channel Analog Input+
19 AINL- Left Channel Analog Input-
18 FILT Internal Voltage Filter
17 AINR- Right Channel Analog Input-
16 AINR+ Right Channel Analog Input+
15 MUTEC Mute Control

• BA4560F





8. Internal Block Diagram of ICs

DHC-XD350

• STA500



8. Internal Block Diagram of ICs

DHC-XD350

• CS4341




Reset RST 1 16 MUTEC Mute Control
Serial Data SDATA 2 15 AOUTA Analog Output A
Serial Clock SCLK 3 14 VA Analog Power
t/Right Clock LRCK 4 13 AGND Analog Ground
Master Clock MCLK 5 12 AOUTB Analog Output B
SCL/CCLK SCL/CCLK 6 11 REF_GND Reference Ground
SDA/CDIN SDA/CDIN 7 10 VQ Quiescent Voltage
AD0/CS AD0/CS 8 9 FILT+ Positive Voltage Reference

• CS4955





• 74VHC14



• 74VHC157



8. Internal Block Diagram of ICs

DHC-XD350

- ES4408



- 74HC244

Connection Diagram



Top View

Truth Table

$1\overline{G}$	1A	1Y	$2\overline{G}$	2A	2Y
L	L	L	L	L	L
L	H	H	L	H	H
H	L	Z	H	L	Z
H	H	Z	H	H	Z

H HIGH Level
L LOW Level
Z High Impedance

8. Internal Block Diagram of ICs

DHC-XD350

- HY57V161610DTC-8





8. Internal Block Diagram of ICs

DHC-XD350

• LA7952



• NJM4558M







• NJU7313A





9. Block Diagram

DHC-XD350 MAIN BLOCK



9. Block Diagram

DHC-XD350 IN/OUT BLOCK



9. Block Diagram

DHC-XD350 REGULATOR BLOCK



10. Wiring Diagram

DHC-XD350



11. Schematic Diagram

-. AMP

DHC-XD350



11. Schematic Diagram

-. FRONT

DHC-XD350



* TUNER BAND OPTION

Version / BAND	America 1/12Hr	America 2/12Hr	Eur 2Band /24Hr	Japan /12Hr	Asia 1/12Hr	Asia 2/24Hr	CIS /24Hr	Latin Am /12Hr	Eur Rds 2b/24Hr
FM(MHz)/Step	FM 87.5-108/100	FM 87.5-108.1/200	FM 87.5-108/50	FM 76-108/100	FM 87.5-108/100	FM 87.5-108/100	FM L:65-71/10	FM 87.5-108/100	FM 87.5-108/50
FM(MHz)/Step							FM H:87.5-108/50		
MW(kHz)/Step	AM 530-1710/10	AM 530-1710/10	MW 522-1620/9	AM 522-1620/9	AM 522-1620/9	AM 522-1620/9	AM 522-1620/9	AM 530-1620/10	MW 522-1620/9
LW(kHz)/Step									
HR734	Jump	330	1.2K	1.8K	2.7K	3.9K	6.8K	10K	22K

11. Schematic Diagram

-. DDX

DHC-XD350



11. Schematic Diagram

-. IO

DHC-XD350



11. Schematic Diagram

-. MPEG DECODER

DHC-XD350



11. Schematic Diagram

-. MPEG OUTPUT

DHC-XD350



11. Schematic Diagram

-. REGULATOR

DHC-XD350



12. Printed Circuit Diagram

-. Front PCB

1) DHC-XD350 Front PCB

1-1) TOP View



1-2) BOTTOM View



12. Printed Circuit Diagram

-. IO PCB

1) TOP View



2) BOTTOM View



12. Printed Circuit Diagram

-. MPEG PCB

1) TOP View



2) BOTTOM View



12. Printed Circuit Diagram

-. MAIN PCB

DHC-XD350

1) TOP View



12. Printed Circuit Diagram

-. MAIN PCB

DHC-XD350

2) BOTTOM View



Drill Symbol Table		
Hole Dia (mm)	Symbol	Quantity
0.60		770
0.70		2
0.80		100
0.90		3
1.00		208
1.20		4
1.50		8

12. Printed Circuit Diagram

-. REGULATOR PCB
DHC-XD350



-. STANDBY PCB
DHC-XD350



13. Mechanism

DHC-XD350



NO.	PART NO.	PART NAME	MATERIAL	COLOR/FINISH	Q'TY	REMARKS
A	EMT100001000	SPINDLE,MOTOR				
B	EPU100002000	P/U				
C	EMT200000000	MOTOR,GEAR				
D	EMT200000000	MOTOR,GEAR				
E	ESW055001100	DETECTOR SWITCH				

NO.	PART NO.	PART NAME	MATERIAL	COLOR/FINISH	Q'TY	REMARKS
9	MSC20000300	SCREW,TAP(PCBA,MAIN)	MS	NZ	3	T2PA+2.6X6.0X6.5
8	MPR31010000	COVER,BTM	SECC 0.6T		1	
7	EPB17000000	PCBA,MAIN			1	
6	MAY01000000	AY LOADING			1	
5	MSC20000300	SCREW,TAP(COVER,TOP)	MS	NZ	2	T2PA+2.6X6.0X6.5
4	MAY01000200	AY T/COVER			1	
3	MMU31000000	TRAY,DISC	PC+ABS,V2	BLK	1	V2
2	MSC20000200	SCREW,TAP(DAMPER)	MS	NZ	3	T2WS+1.7X5.0X8.0
1	MAY01000100	AY FEEDING				

14. Exploded View and Mechanical Parts List

DHC-XD350



14. Exploded View and Mechanical Parts List

DHC-XD350

NO.	NAME OF PART	DHC-XD300	DHC-XD350	DISCRIPTION	Q'TY	REMARKS
1	PANEL FRONT	9CD0310000	9CD0310400	MIPS	1	
2	DOOR HOLDER	9CD1813400	¡	MIPS	1	
3	KNOB POWER	9CD1346900	9CD1347400	MIPS	1	
4	KNOB VOLUME	9CD1347000	9CD1347700	MIPS ABS	1	
5	KNOB STAND BY	9CD1347100	9CD1347500	MIPS ABS	1	
6	KNOB PRESET	9CD1347200	9CD1347600	MIPS ABS	1	
7	LENS LED	9CD1619100	9CD1619200	ACRYL	1	
8	GUIDE FLT	9CD2507300	¡	MIPS	1	
9	SUPPORT PCB 08	9CD2507400	¡	MIPS	12	
10	SUPPORT PCB 12	9CD2507401	¡	MIPS	3	
11	CHASSIS BOTTOM	9CD0608900	¡	SECC	1	
12	CHASSIS TOP	9CD0609000	¡	SECC	1	
13	CHASSIS BACK	9CD0609103	9CD0609109	SECC	1	
14	DECO FRONT	9CD1004000	9CD1004200	ACRYL	1	
15	DECO DVD DOOR	9CD1004100	¡	ACRYL	1	
16	MECHANISM DVD	9CD6010300	¡		1	
17	HEAT SINK	9CD4406900	¡	AL	1	
18	HEAT SINK TR	9CD4407100	¡	AL	1	
19	HEAT SINK IC	9CD4407000	¡	BsP	1	
20	HEAT SINK DIODE	9CD44066D0	¡	AL	2	
21	PLATE SPEAKER	9CD0912600	¡	PC	1	
22	CUSHION FOOT	9CD4209000	¡	RUBBER	4	
23	RUBBER SILICON	9CD4209100	¡	RUBBER	6	
24	SPRING GROUND	9CD3009000	¡	BsP	1	
25	CUSHION FOOT	9CD4207700	¡	RUBBER	6	
26	BADGE DAEWOO	-	9CD1502500	AL	1	
S1	SCREW TAPPING	7173301012	¡		13 11	
S2	SCREW TAPPING	7173301412	¡		14	
S3	SCREW TAPPING	7173300811	¡		15	
S4	SCREW TAPPING	7173261011	¡		8	
S5	SCREW TAPPING	7173400611	¡		4	
S6	SCREW TAPPING	7173301812	¡		3	
S7	SCREW TAPPING	7173301013	¡		2	
S8	SCREW TAPPING	7273300812	¡		4	
P1	PCB FRONT	9CD6586600	9CD6587200		1	
P2	PCB STAND BY	9CD6586900	¡		1	
P3	PCB MAIN	9CD6586400	¡		1	
P4	PCB IN OUT	9CD6586800	¡		1	
P5	PCB REGULATOR	9CD6586700	¡		1	
P6	PCB MPEG	9CD6586500	¡		1	
E1	POWER TRANS				1	
E2	TUNER PACK				1	
E3	VFD				1	
E4	AC CORD				1	

15. Electrical Parts List

DHC-XD350

NO	PART-NAME	LOCATION	PART-CODE	PART-DESC	XD300	XD350
1	TUNER MODULE	TU001	9737650501	KST-MV114MA1-0	O	O
1	PCB FRONT AS	11000	9CDC060900	DV-215	O	O
2	PCB FRONT	B700	9CD6586600	289.5X122.5XT1.6	O	O
3	C ELECTRO	CE700	CEXP1C470V	16V REM 47MF	O	O
4	C ELECTRO	CE701	CEXP1A221V	10V REM 220MF	O	O
5	C ELECTRO	CE702	CEXP1H109V	50V REM 1MF 4*5	O	O
6	C ELECTRO	CE703	CEXP1C470V	16V REM 47MF	O	O
7	CONN AS	CN702	9728815800	#26 UL2547 SHIELD 3P BOARD-IN	O	O
8	CONN AS	CN703	9728814300	#26 8P PITCH 2.0 200MM BOARD IN	O	O
9	CONN WAFER	CW701	9CD6269500	52807-0610	O	O
10	CONN WAFER	CW702	9CD6269500	52807-0610	O	O
11	CONN WAFER	CW704	9CD6269500	52807-0610	O	O
12	CONN WAFER	CW705	9CD6271200	52807-2510	O	O
13	DIODE ZENER	DZ700~701	DZTZ4R3B--	MTZ4.3B	O	O
14	FL DISPLAY	FL700	DHNA12SM21	HNA-12SM21	O	O
15	CORE RING	HB700~701	9CD8603400	74279409 PI8.0X9.5X3.5	O	O
16	COIL CHIP	HB702~703	HLC104J01A	BEAD 120 OHM 100MHZ 2012	O	O
17	COIL CHIP	HB705	HLC104J01A	BEAD 120 OHM 100MHZ 2012	O	O
18	C CHIP CERA	HC700~701	HCBK223KBA	50V X7R 0.022MF K 1608	O	O
19	C CHIP CERA	HC702~704	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
20	C CHIP CERA	HC705~706	HCQK101JBA	50V CH 100PF J 1608	O	
21	C CHIP CERA	HC707	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
22	C CHIP CERA	HC708~709	HCQK300JBA	50V CH 30PF J 1608	O	O
23	C CHIP CERA	HC710~713	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
24	C CHIP CERA	HC711	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
25	DIODE SW CHIP	HD700~703	DZDS160---	KDS160	O	O
26	TR CHIP	HQ700~702	TZRC102S--	KRC102S	O	O
27	R CHIP	HR701~702	HRFT101JBA	1/10 100 OHM J 1608	O	O
28	R CHIP	HR703	HRFT100JBA	1/10 10 OHM J 1608	O	O
29	R CHIP	HR704~705	HRFT103JBA	1/10 10K OHM J 1608	O	O
30	R CHIP	HR706	HRFT101JBA	1/10 100 OHM J 1608	O	O
31	R CHIP	HR707	HRFT103JBA	1/10 10K OHM J 1608	O	O
32	R CHIP	HR708	HRFT101JBA	1/10 100 OHM J 1608	O	O
33	R CHIP	HR709	HRFT103JBA	1/10 10K OHM J 1608	O	O
34	R CHIP	HR710~712	HRFT101JBA	1/10 100 OHM J 1608	O	O
35	R CHIP	HR713	HRFT103JBA	1/10 10K OHM J 1608	O	O
36	R CHIP	HR714	HRF8331JCA	1/8 330 OHM J 2012	O	O
37	R CHIP	HR715~717	HRFT103JBA	1/10 10K OHM J 1608	O	O
38	R CHIP	HR718~719	HRFT473JBA	1/10 47K OHM J 1608	O	
39	R CHIP	HR720	HRFT100JBA	1/10 10 OHM J 1608	O	O
40	R CHIP	HR721~722	HRFT152JBA	1/10 1.5K OHM J 1608	O	O
41	R CHIP	HR723~727	HRFT101JBA	1/10 100 OHM J 1608	O	O
42	R CHIP	HR728	HRFT151JBA	1/10 150 OHM J 1608	O	O
43	R CHIP	HR729	HRFT101JBA	1/10 100 OHM J 1608	O	O
44	R CHIP	HR730	HRFT181JBA	1/10 180 OHM J 1608	O	O
45	R CHIP	HR731	HRFT271JBA	1/10 270 OHM J 1608	O	O
46	R CHIP	HR732	HRFT472JBA	1/10 4.7K OHM J 1608	O	O
47	R CHIP	HR733	HRFT103JBA	1/10 10K OHM J 1608	O	O
48	R CHIP	HR734	HRFT333JBA	1/10 33K OHM J 1608	O	O
49	R CHIP	HR735~736	HRFT562JBA	1/10 5.6K OHM J 1608	O	O
50	R CHIP	HR737	HRFT103JBA	1/10 10K OHM J 1608	O	O
51	R CHIP	HR738	HRFT562JBA	1/10 5.6K OHM J 1608	O	
52	R CHIP	HR738	HRFT151JBA	1/10 150 OHM J		O
53	R CHIP	HR739	HRFT181JBA	1/10 180 OHM J		O
54	R CHIP	HR740~742	HRFT103JBA	1/10 10K OHM J 1608	O	O
55	R CHIP	HR743~745	HRFT000JBA	1/10 0 OHM J 1608	O	O
56	R CHIP	HR746~748	HRFT222JBA	1/10 2.2K OHM J 1608	O	O
57	R CHIP	HR750	HRFT562JBA	1/10 5.6K OHM J		O
58	IC	IC701	1M24C04MN-	M24C04MN S0P	O	O
59	IC RMC	IC702	1354HF----	354HF	O	O
60	IC	IC703	1M38B7----	M38B7-XD300	O	O
61	JACK	J700	9736322800	HTJ-035-18A(KUNMING)	O	O
62	LED	LD700	DLTL16KGE-	LTL-16KGE(GREEN)PI3.1	O	
63	LED	LD700	DLTL16KEE-	LTL-16KEE(RED)PI3.1		O
64	TR	Q702	TZTA1272Y-	KTA1272-Y (AUTO)	O	O
65	SW TACT	SW700~706	5S50101001	KPT-1105A 1C-1P	O	O
66	SW TACT	SW707~708	5S50101001	KPT-1105A 1C-1P		O
67	SW PUSH	SW710	5S40101373	SPEA122SC011	O	O
68	SW ENCORDER	VR700	5SH162401-	EC16B24204 24P W/DETENT	O	
69	CONN FFC	WC700	9728815900	FFC 6P P=1.0X100MM K	O	O
70	CONN FFC	WC701	9728816000	FFC 6P P=1.0X150M K	O	O
71	CONN FFC	WC702	9728816100	FFC 25P P=1.0X370MM K	O	O
72	RESO CERA	XC700	5PCSA4R190	CSA 4.19M	O	O
1	PCB INOUT AS	14000	9CDC061200	DV-215	O	O
2	PCB INOUT	B401	9CD6586800	80X169	O	O
3	C ELECTRO	CE402~403	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
4	C ELECTRO	CE405~406	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
5	C ELECTRO	CE407~410	CEXF1H479V	50V RSS 4.7MF (5X11) TP	O	O
6	C ELECTRO	CE411~412	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
7	C ELECTRO	CE413	CEXF1C471V	16V RSS 470MF (8X12)TP	O	O
8	C ELECTRO	CE414	CEXF1E101V	25V RSS 100MF (6.3X11) TP	O	O
9	C ELECTRO	CE415	CEXF1C471V	16V RSS 470MF (8X12)TP	O	O
10	C ELECTRO	CE416~417	CEXF1E101V	25V RSS 100MF (6.3X11) TP	O	O
11	C ELECTRO	CE418~425	CEXF1H100V	50V RSS 10MF (5X11) TP	O	O
12	C ELECTRO	CE426~427	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
13	C ELECTRO	CE428	CEXF1C471V	16V RSS 470MF (8X12)TP	O	O
14	CONN WAFER	CW401	9CD6269100	52806-2710	O	O
15	CONN WAFER	CW408	9CD6267600	52806-1110	O	O
16	C CHIP CERA	HC403	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
17	C CHIP CERA	HC404	HCQK220JBA	50V CH 22PF J 1608	O	O
18	C CHIP CERA	HC405~406	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
19	C CHIP CERA	HC409~410	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
20	C CHIP CERA	HC411~412	HCQK101JBA	50V CH 100PF J 1608	O	O
21	C CHIP CERA	HC415~416	HCQK101JBA	50V CH 100PF J 1608	O	O
22	C CHIP CERA	HC419~420	HCQK101JBA	50V CH 100PF J 1608	O	O
23	C CHIP CERA	HC423	HCQK101JBA	50V CH 100PF J 1608	O	O
24	C CHIP CERA	HC424	HCBK473KBA	50V X7R 0.047MF K 1608	O	O
25	C CHIP CERA	HC425~426	HCBK103KBA	50V X7R 0.01MF K 1608	O	O
26	C CHIP CERA	HC427~428	HCBK102KBA	50V X7R 1000PF K 1608	O	O
27	C CHIP CERA	HC429~430	HCBK103KBA	50V X7R 0.01MF K 1608	O	O
28	C CHIP CERA	HC431	HCQK101JBA	50V CH 100PF J 1608	O	O
29	C CHIP CERA	HC432	HCBK103KBA	50V X7R 0.01MF K 1608	O	O
30	C CHIP CERA	HC434~435	HCBK103KBA	50V X7R 0.01MF K 1608	O	O
31	C CHIP CERA	HC437~438	HCQK101JBA	50V CH 100PF J 1608	O	O

15. Electrical Parts List

DHC-XD350

NO	PART-NAME	LOCATION	PART-CODE	PART-DESC	XD300	XD350
32	C CHIP CERA	HC439	HCBK103KBA	50V X7R 0.01MF K 1608	O	O
33	DIODE SW CHIP	HD402~404	DZDS160---	KDS160	O	O
34	DIODE SW CHIP	HD411~422	DZDS160---	KDS160	O	O
35	COIL CHIP	HL402	HLC479J03A	4.7UH CHIP 2012	O	O
36	COIL CHIP	HL404~418	HLC104J01A	BEAD 120 OHM 100MHZ 2012	O	O
37	COIL CHIP	HL420~424	HLC104J01A	BEAD 120 OHM 100MHZ 2012	O	O
38	COIL CHIP	HL428~429	HLC104J01A	BEAD 120 OHM 100MHZ 2012	O	O
39	TR CHIP	HQ401~402	TZTC3875Y-	KTC3875Y	O	O
40	TR CHIP	HQ403~404	TZRC107S--	KRC107S	O	O
41	TR CHIP	HQ405	TZTC3875Y-	KTC3875Y	O	O
42	TR CHIP	HQ406	TZRC107S--	KRC107S	O	O
43	TR CHIP	HQ407	TZRA102S--	KRA102S (10X10)PNP	O	O
44	TR CHIP	HQ408	TZRC107S--	KRC107S	O	O
45	R CHIP	HR401	HRFT472JBA	1/10 4.7K OHM J 1608	O	O
46	R CHIP	HR403	HRFT221JBA	1/10 220 OHM J 1608	O	O
47	R CHIP	HR409~410	HRFT101JBA	1/10 100 OHM J 1608	O	O
48	R CHIP	HR411~414	HRFT104JBA	1/10 100K OHM J 1608	O	O
49	R CHIP	HR415~416	HRFT750JBA	1/10 75 OHM J 1608	O	O
50	R CHIP	HR417~418	HRFT104JBA	1/10 100K OHM J 1608	O	O
51	R CHIP	HR419~420	HRFT750JBA	1/10 75 OHM J 1608	O	O
52	R CHIP	HR421~422	HRFT104JBA	1/10 100K OHM J 1608	O	O
53	R CHIP	HR423~424	HRFT750JBA	1/10 75 OHM J 1608	O	O
54	R CHIP	HR425	HRFT221JBA	1/10 220 OHM J 1608	O	O
55	R CHIP	HR426	HRFT104JBA	1/10 100K OHM J 1608	O	O
56	R CHIP	HR427~431	HRFT101JBA	1/10 100 OHM J 1608	O	O
57	R CHIP	HR432	HRFT680JBA	1/10 68 OHM J 1608	O	O
58	R CHIP	HR433	HRFT473JBA	1/10 47K OHM J 1608	O	O
59	R CHIP	HR434	HRFT391JBA	1/10 390 OHM J 1608	O	O
60	R CHIP	HR435	HRFT750JBA	1/10 75 OHM J 1608	O	O
61	R CHIP	HR436	HRFT332JBA	1/10 3.3K OHM J 1608	O	O
62	R CHIP	HR437	HRFT680JBA	1/10 68 OHM J 1608	O	O
63	R CHIP	HR438	HRFT473JBA	1/10 47K OHM J 1608	O	O
64	R CHIP	HR439	HRFT391JBA	1/10 390 OHM J 1608	O	O
65	R CHIP	HR440	HRFT473JBA	1/10 47K OHM J 1608	O	O
66	R CHIP	HR441~442	HRFT104JBA	1/10 100K OHM J 1608	O	O
67	R CHIP	HR443~446	HRFT101JBA	1/10 100 OHM J 1608	O	O
68	R CHIP	HR447~450	HRFT104JBA	1/10 100K OHM J 1608	O	O
69	R CHIP	HR451~452	HRFT472JBA	1/10 4.7K OHM J 1608	O	O
70	R CHIP	HR453~454	HRFT101JBA	1/10 100 OHM J 1608	O	O
71	R CHIP	HR455~456	HRFT104JBA	1/10 100K OHM J 1608	O	O
72	R CHIP	HR457	HRFT750JBA	1/10 75 OHM J 1608	O	O
73	R CHIP	HR458	HRFT391JBA	1/10 390 OHM J 1608	O	O
74	R CHIP	HR459	HRFT473JBA	1/10 47K OHM J 1608	O	O
75	R CHIP	HR460	HRFT680JBA	1/10 68 OHM J 1608	O	O
76	R CHIP	HR461~462	HRFT104JBA	1/10 100K OHM J 1608	O	O
77	R CHIP	HR463~464	HRFT750JBA	1/10 75 OHM J 1608	O	O
78	R CHIP	HR465~466	HRFT102JBA	1/10 1K OHM J 1608	O	O
79	R CHIP	HR468	HRFT101JBA	1/10 100 OHM J 1608	O	O
80	IC SWITCH	IC401	1NJU7313A-	NJU7313A (SW ARRAY)	O	O
81	IC CHIP	IC402~403	1NJM4558M-	NJM4558M	O	O
82	IC SWITCH	IC404	1LA7952---	LA7952	O	O
83	IC	IC405	174HCU04--	74HCU04 (INVERTER)	O	O

NO	PART-NAME	LOCATION	PART-CODE	PART-DESC	XD300	XD350
84	IC CHIP	IC406	1NJM4558M-	NJM4558M	O	O
85	IC TX	IC407	1TX0C0805-	OC0805-TX	O	O
86	JACK RCA 9P	J401	9736325100	JB090148 (RCA 9P)	O	O
87	JACK S-VIDEO	J402	9736325200	C5026030 (S-VIDEO+RCA)	O	O
88	JACK SCART	J403	9736324800	21P	O	O
89	CONN FFC	WC400	9728816400	FFC 27P P=1.0X100MM R	O	O
1	PCB MAIN AS	10000	9CDC060800	DV-215	O	O
2	PCB MAIN	B800	9CD6586400	234X208 CEM-3	O	O
3	C ELECTRO	CE201~204	CEXF1H100V	50V RSS 10MF (5X11) TP	O	O
4	C ELECTRO	CE205~206	CEXF1H479V	50V RSS 4.7MF (5X11) TP	O	O
5	C ELECTRO	CE215~216	CEXF1H479V	50V RSS 4.7MF (5X11) TP	O	O
6	C ELECTRO	CE217	CEXF1H109V	50V RSS 1MF (5X11) TP	O	O
7	C ELECTRO	CE218	CEXF1H108V	50V RSS 0.1MF (5X11) TP	O	O
8	C ELECTRO	CE219~220	CEXF1E101V	25V RSS 100MF (6.3X11) TP	O	O
9	C ELECTRO	CE221~222	CEXF1H100V	50V RSS 10MF (5X11) TP	O	O
10	C ELECTRO	CE223	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
11	C ELECTRO	CE224~227	CEXF1H479V	50V RSS 4.7MF (5X11) TP	O	O
12	C ELECTRO	CE228~229	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
13	C ELECTRO	CE230	CEXF1H109V	50V RSS 1MF (5X11) TP	O	O
14	C ELECTRO	CE231	CEYF1A102V	10V 1000MF RSS 10X16	O	O
15	C ELECTRO	CE232	CEXF1H109V	50V RSS 1MF (5X11) TP	O	O
16	C ELECTRO	CE233	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
17	C ELECTRO	CE234	CEXF1H100V	50V RSS 10MF (5X11) TP	O	O
18	C ELECTRO	CE235~236	CEXF1H479V	50V RSS 4.7MF (5X11) TP	O	O
19	C ELECTRO	CE237	CEXF1H100V	50V RSS 10MF (5X11) TP	O	O
20	C ELECTRO	CE238	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
21	C ELECTRO	CE239	CEXF1H479V	50V RSS 4.7MF (5X11) TP	O	O
22	C ELECTRO	CE240~242	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
23	C ELECTRO	CE243~244	CEXF1H109V	50V RSS 1MF (5X11) TP	O	O
24	C ELECTRO	CE245~246	CEXF1H479V	50V RSS 4.7MF (5X11) TP	O	O
25	C ELECTRO	CE801~803	CEYF1V102V	35V RSS 1000MF (13X25)	O	O
26	C ELECTRO	CE804~805	CEYF1V472V	35V RSS 4700MF (22X40)	O	O
27	C MYLAR	CM801~812	CMXK1J104J	MC 63V 0.1MF J	O	O
28	C MYLAR	CM813~818	CMXK1J474J	MC 63V 0.47MF J	O	O
29	C MYLAR	CM819~830	CMXM2A682J	100V 6800PF J (TP)	O	O
30	C MYLAR	CM831~842	CMXK1J104J	MC 63V 0.1MF J	O	O
31	C MYLAR	CM991~993	CMXM2A104J	100V 0.1MF J (TP)	O	O
32	CONN WAFER	CW101	9CD6264500	52045-1345 TOP ENTRY	O	O
33	CONN WAFER	CW201	9CD6269100	52806-2710	O	O
34	CONN AS	CW202	9728811400	P2.0 3P 270MM SHIELD	O	O
35	CONN WAFER	CW203	9CD6267300	52806-0810	O	O
36	CONN WAFER	CW205	9CD6269000	52806-2510	O	O
37	CONN WAFER	CW991	9728808400	VH-2A WAFER	O	O
38	CONN AS	CW993	9728814900	#22 6P P=2.0 150MM	O	O
39	DIODE	DB991	DKBPC806--	KBPC806	O	O
40	C CHIP CERA	HC201~202	HCQK561JBA	50V CH 560PF J 1608	O	O
41	C CHIP CERA	HC203~204	HCQK121JBA	50V CH 120PF J 1608	O	O
42	C CHIP CERA	HC205~206	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
43	C CHIP CERA	HC207~208	HCQK101JBA	50V CH 100PF J 1608	O	O
44	C CHIP CERA	HC209~210	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
45	C CHIP CERA	HC221~222	HCBK103KBA	50V X7R 0.01MF K 1608	O	O
46	C CHIP CERA	HC223	HCBK104KBA	50V X7R 0.1MF K 1608	O	O

15. Electrical Parts List

DHC-XD350

NO	PART-NAME	LOCATION	PART-CODE	PART-DESC	XD300	XD350
47	C CHIP CERA	HC224	HCBK105KBA	50V X7R 1MF K 1608	O	O
48	C CHIP CERA	HC225~226	HCBK222KBA	50V X7R 2200PF K 1608	O	O
49	C CHIP CERA	HC227~231	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
50	C CHIP CERA	HC232~233	HCQK160JBA	50V CH 16PF J 1608	O	O
51	C CHIP CERA	HC234~239	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
52	C CHIP CERA	HC240~241	HCQK101JBA	50V CH 100PF J 1608	O	O
53	C CHIP CERA	HC242~243	HCQK681JBA	50V CH 680PF J 1608	O	O
54	C CHIP CERA	HC244~245	HCQK471JBA	50V CH 470PF J 1608	O	O
55	C CHIP CERA	HC246~253	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
56	C CHIP CERA	HC254	HCQK101JBA	50V CH 100PF J 1608	O	O
57	C CHIP CERA	HC255	HCQK561JBA	50V CH 560PF J 1608	O	O
58	C CHIP CERA	HC256	HCQK121JBA	50V CH 120PF J 1608	O	O
59	C CHIP CERA	HC257	HCQK221JBA	50V CH 220PF J 1608	O	O
60	C CHIP CERA	HC258~260	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
61	C CHIP CERA	HC261	HCQK220JBA	50V CH 22PF J 1608	O	O
62	C CHIP CERA	HC262~265	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
63	C CERA	HC266~267	CCZB1H331K	50V B 330PF K (AXIAL)	O	O
64	C CHIP CERA	HC801~809	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
65	C CHIP CERA	HC811~814	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
66	C CHIP CERA	HC816	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
67	C CHIP CERA	HC818	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
68	C CHIP CERA	HC820~825	HCBK331KBA	50V Y5V 330PF J 1608	O	O
69	CHIP TANTAL CAP	HC826~831	HCTAJ105KB	TSM1V105ASSR(1UF/35V,3216)	O	O
70	DIODE SW CHIP	HD201~202	DZDS160---	KDS160	O	O
71	R CHIP	HL201~204	HRFT000-BA	1/10 0 OHM 1608	O	O
72	R CHIP	HL205~206	HRFT100JBA	1/10 10 OHM J 1608	O	O
73	R CHIP	HL207	HRFT000-BA	1/10 0 OHM 1608	O	O
74	R CHIP	HL211~221	HRFT000-BA	1/10 0 OHM 1608	O	O
75	R CHIP	HL223~225	HRFT000-BA	1/10 0 OHM 1608	O	O
76	R CHIP	HL229~231	HRFT000-BA	1/10 0 OHM 1608	O	O
77	R CHIP	HL249~250	HRFT000-BA	1/10 0 OHM 1608	O	O
78	R CHIP	HL801~803	HRFT000-BA	1/10 0 OHM 1608	O	O
79	TR CHIP	HQ201	TZRC231S--	KRC231S	O	O
80	TR CHIP	HQ203~204	TZRC231S--	KRC231S	O	O
81	TR CHIP	HQ991	TZRC107S--	KRC107S	O	O
82	R CHIP	HR200	HRFT100JBA	1/10 10 OHM J 1608	O	O
83	R CHIP	HR201~202	HRFT103JBA	1/10 10K OHM J 1608	O	O
84	R CHIP	HR203~204	HRFT122JBA	1/10 1.2K OHM J 1608	O	O
85	R CHIP	HR205~206	HRFT183JBA	1/10 18K OHM J 1608	O	O
86	R CHIP	HR207~208	HRFT473JBA	1/10 47K OHM J 1608	O	O
87	R CHIP	HR209~212	HRFT123JBA	1/10 12K OHM J 1608	O	O
88	R CHIP	HR213~214	HRFT224JBA	1/10 220K OHM J 1608	O	O
89	R CHIP	HR215~216	HRFT101JBA	1/10 100 OHM J 1608	O	O
90	R CHIP	HR217	HRFT183JBA	1/10 18K OHM J 1608	O	O
91	R CHIP	HR218	HRFT123JBA	1/10 12K OHM J 1608	O	O
92	R CHIP	HR219	HRFT104JBA	1/10 100K OHM J 1608	O	O
93	R CHIP	HR220	HRFT123JBA	1/10 12K OHM J 1608	O	O
94	R CHIP	HR221	HRFT224JBA	1/10 220K OHM J 1608	O	O
95	R CHIP	HR222	HRFT101JBA	1/10 100 OHM J 1608	O	O
96	R CHIP	HR223	HRFT103JBA	1/10 10K OHM J 1608	O	O
97	R CHIP	HR224~225	HRFT100JBA	1/10 10 OHM J 1608	O	O
98	R CHIP	HR226	HRFT331JBA	1/10 330 OHM J 1608	O	O

NO	PART-NAME	LOCATION	PART-CODE	PART-DESC	XD300	XD350
99	R CHIP	HR227~228	HRF4220JEA	1/4W 22 OHM J 3216	O	O
100	R CHIP	HR229~230	HRFT220JBA	1/10W 22 OHM J 1608	O	O
101	R CHIP	HR234~235	HRFT103JBA	1/10 10K OHM J 1608	O	O
102	R CHIP	HR236	HRFT104JBA	1/10 100K OHM J 1608	O	O
103	R CHIP	HR237~238	HRF4220JEA	1/4W 22 OHM J 3216	O	O
104	R CHIP	HR239~240	HRFT561JBA	1/10 560 OHM J 1608	O	O
105	R CHIP	HR241~242	HRFT104JBA	1/10 100K OHM J 1608	O	O
106	R CHIP	HR243~244	HRFT151JBA	1/10 150 OHM J 1608	O	O
107	R CHIP	HR245	HRFT222JBA	1/10 2.2K OHM J 1608	O	O
108	R CHIP	HR246~247	HRFT000-BA	1/10 0 OHM 1608	O	O
109	R CHIP	HR250	HRFT100JBA	1/10 10 OHM J 1608	O	O
110	R CHIP	HR251~252	HRFT220JBA	1/10W 22 OHM J 1608	O	O
111	R CHIP	HR253	HRFT103JBA	1/10 10K OHM J 1608	O	O
112	R CHIP	HR254	HRFT105JBA	1/10 1M OHM J 1608	O	O
113	R CHIP	HR255	HRFT473JBA	1/10 47K OHM J 1608	O	O
114	R CHIP	HR256	HRFT471JBA	1/10 470 OHM J 1608	O	O
115	R CHIP	HR257~259	HRFT220JBA	1/10W 22 OHM J 1608	O	O
116	R CHIP	HR260	HRFT100JBA	1/10 10 OHM J 1608	O	O
117	R CHIP	HR261~264	HRFT220JBA	1/10W 22 OHM J 1608	O	O
118	R CHIP	HR265	HRFT473JBA	1/10 47K OHM J 1608	O	O
119	R CHIP	HR267	HRFT100JBA	1/10 10 OHM J 1608	O	O
120	R CHIP	HR268~269	HRFT220JBA	1/10W 22 OHM J 1608	O	O
121	R CHIP	HR270	HRFT100JBA	1/10 10 OHM J 1608	O	O
122	R CHIP	HR271	HRFT471JBA	1/10 470 OHM J 1608	O	O
123	R CHIP	HR272~274	HRFT220JBA	1/10W 22 OHM J 1608	O	O
124	R CHIP	HR275~277	HRFT000-BA	1/10 0 OHM 1608	O	O
125	R CHIP	HR278~280	HRFT220JBA	1/10W 22 OHM J 1608	O	O
126	R CHIP	HR281~282	HRFT561JBA	1/10 560 OHM J 1608	O	O
127	R CHIP	HR283~286	HRFT104JBA	1/10 100K OHM J 1608	O	O
128	R CHIP	HR287~288	HRFT821JBA	1/10 820 OHM J 1608	O	O
129	R CHIP	HR289~292	HRFT103JBA	1/10 10K OHM J 1608	O	O
130	R CHIP	HR293~295	HRFT220JBA	1/10W 22 OHM J 1608	O	O
131	R CHIP	HR296	HRFT104JBA	1/10 100K OHM J 1608	O	O
132	R CHIP	HR297	HRFT561JBA	1/10 560 OHM J 1608	O	O
133	R CHIP	HR298	HRFT472JBA	1/10 4.7K OHM J 1608	O	O
134	R CHIP	HR299	HRFT122JBA	1/10 1.2K OHM J 1608	O	O
135	R CHIP	HR300	HRFT333JBA	1/10 33K OHM J 1608	O	O
136	R CHIP	HR301	HRFT100JBA	1/10 10 OHM J 1608	O	O
137	R CHIP	HR801~812	HRFT000-BA	1/10 0 OHM 1608	O	O
138	R CHIP	HR813~815	HRFT100JBA	1/10 10 OHM J 1608	O	O
139	R CHIP	HR816	HRFT103JBA	1/10 10K OHM J 1608	O	O
140	R CHIP	HR819	HRFT103JBA	1/10 10K OHM J 1608	O	O
141	R CHIP	HR822~833	HRF4569JEA	1/4W 5.6 OHM J 3216	O	O
142	R CHIP	HR834~839	HRF4220JEA	1/4W 22 OHM J 3216	O	O
143	R CHIP	HR840	HRFT103JBA	1/10 10K OHM J 1608	O	O
144	R CHIP	HR843~845	HRFT103JBA	1/10 10K OHM J 1608	O	O
145	DIODE ZENER CHIP	HZ991	DRLZ30B---	RLZ30B	O	O
146	DIODE ZENER CHIP	HZ992	DRLZ4R7B--	RLZ4.7B	O	O
147	IC DDX	IC201~202	1STA304A--	STA304A	O	O
148	IC	IC203~204	1CS4341---	CS4341 (DAC)	O	O
149	IC AMP(CHIP TYPE)	IC205	1BA4560F--	BA4560F	O	O
150	IC CHIP	IC206	1NJM4558M-	NJM4558M	O	O

15. Electrical Parts List

DHC-XD350

NO	PART-NAME	LOCATION	PART-CODE	PART-DESC	XD300	XD350
151	IC REGULATOR	IC207	1LD1117S33	LD117AS33TR 3.3V (TO-223)	O	O
152	IC	IC208	1CS4228A--	CS4228A (CODEC)	O	O
153	IC CHIP	IC209~210	1NJM4558M-	NJM4558M	O	O
154	IC	IC211~212	174VHC157M	74VHC157MTC	O	O
155	IC	IC213	174VHC14MT	74VHCMTC TSSOP	O	O
156	IC PWM AMP	IC801~803	1STA500---	STA500	O	O
157	JACK SPK	J801	9736325000	PA1220601P	O	O
158	COIL FILTER	L801~812	5P8080P220	8080P-13-220K	O	O
159	CONN FFC	WC100	9728816500	FFC 13P P=1.25X100MM R	O	O
160	X-TAL	XC201	5XE6R1440J	6.144MHZ	O	O
1	PCB MPEG AS	12000	9CDC061000	DV-215	O	O
2	PCB MPEG	B501	9CD6586500	150X150	O	O
3	C ELECTRO	CE506	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
4	C ELECTRO	CE523	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
5	C ELECTRO	CE611~613	CEXF1C471V	16V RSS 470MF (8X12)TP	O	O
6	C ELECTRO	CE618	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
7	C ELECTRO	CE619	CEXF1C102V	16V RSS 1000MF (10X20) TP	O	O
8	C ELECTRO	CE622	CEXF1C471V	16V RSS 470MF (8X12)TP	O	O
9	CONN AS	CN501	9728815700	ADAPI CABLE 40P 360MM	O	O
10	JACK ATAPI	CW501	9736324700	40P ATAPI	O	O
11	CONN WAFER	CW503	9CD6267300	52806-0810	O	O
12	CONN WAFER	CW504	9CD6267400	52806-0610	O	O
13	CONN AS	CW507	9728814600	#22 4P P=2.0 200MM	O	O
14	CONN WAFER	CW508	9CD6267600	52806-1110	O	O
15	C CHIP CERA	HC501~526	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
16	C CHIP CERA	HC527	HCQK151JBA	50V CH 150PF J 1608	O	O
17	C CHIP CERA	HC528	HCQK330JBA	50V CH 33PF J 1608	O	O
18	C CHIP CERA	HC534~538	HCQK330JBA	50V CH 33PF J 1608	O	O
19	C CHIP CERA	HC539	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
20	C CHIP CERA	HC541	HCBK103KBA	50V X7R 0.01MF K 1608	O	O
21	C CHIP CERA	HC542~546	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
22	C CHIP CERA	HC547	HCBK224KBA	50V X7R 0.22MF K 1608	O	O
23	C CHIP CERA	HC549	HCQK220JBA	50V CH 22PF J 1608	O	O
24	C CHIP CERA	HC550	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
25	C CHIP CERA	HC553~555	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
26	C CHIP CERA	HC574	HCQK150JBA	50V CH 15PF J 1608	O	O
27	C CHIP CERA	HC576	HCQK150JBA	50V CH 15PF J 1608	O	O
28	C CHIP CERA	HC578~579	HCQK470JBA	50V CH 47PF J 1608	O	O
29	C CHIP CERA	HC590	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
30	C CHIP CERA	HC607~608	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
31	C CHIP CERA	HC614~617	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
32	C CHIP CERA	HC619	HCBK104KBA	50V X7R 0.1MF K 1608	O	O
33	C CHIP CERA	HC637~640	HCQK560JBA	50V CH 56PF J 1608	O	O
34	C CHIP CERA	HC645	HCQK560JBA	50V CH 56PF J 1608	O	O
35	C CHIP CERA	HC673	HCQK560JBA	50V CH 56PF J 1608	O	O
36	C CHIP CERA	HC675~676	HCQK100JBA	50V CH 10PF J 1608	O	O
37	C CHIP CERA	HC679	HCQK100JBA	50V CH 10PF J 1608	O	O
38	C CHIP CERA	HC680~685	HCQK560JBA	50V CH 56PF J 1608	O	O
39	TR CHIP	HQ601~603	TZTA1504S-	JTA1504S	O	O
40	R CHIP	HR501~505	HRFT472JBA	1/10 4.7K OHM J 1608	O	O
41	R CHIP	HR511~512	HRFT472JBA	1/10 4.7K OHM J 1608	O	O
42	R CHIP	HR513~519	HRFT470JBA	1/10 47 OHM J 1608	O	O
43	R CHIP	HR520~532	HRFT100JBA	1/10 10 OHM J 1608	O	O
44	R CHIP	HR533~537	HRFT330JBA	1/10 33 OHM J 1608	O	O
45	R CHIP	HR539	HRFT330JBA	1/10 33 OHM J 1608	O	O
46	R CHIP	HR544	HRFT000JBA	1/10 0 OHM J 1608	O	O
47	R CHIP	HR545	HRFT681JBA	1/10 680 OHM J 1608	O	O
48	R CHIP	HR546~547	HRFT105JBA	1/10 1M OHM J 1608	O	O
49	R CHIP	HR549	HRFT100JBA	1/10 10 OHM J 1608	O	O
50	R CHIP	HR550~552	HRFT102JBA	1/10 1K OHM J 1608	O	O
51	R CHIP	HR556	HRFT470JBA	1/10 47 OHM J 1608	O	O
52	R CHIP	HR557~575	HRFT330JBA	1/10 33 OHM J 1608	O	O
53	R CHIP	HR576	HRFT332JBA	1/10 3.3K OHM J 1608	O	O
54	R CHIP	HR577~578	HRFT330JBA	1/10 33 OHM J 1608	O	O
55	R CHIP	HR580~581	HRFT330JBA	1/10 33 OHM J 1608	O	O
56	R CHIP	HR582	HRFT331JBA	1/10 330 OHM J 1608	O	O
57	R CHIP	HR583	HRFT000JBA	1/10 0 OHM J 1608	O	O
58	R CHIP	HR586	HRFT000JBA	1/10 0 OHM J 1608	O	O
59	R CHIP	HR587	HRFT472JBA	1/10 4.7K OHM J 1608	O	O
60	R CHIP	HR588	HRFT330JBA	1/10 33 OHM J 1608	O	O
61	R CHIP	HR589	HRFT000JBA	1/10 0 OHM J 1608	O	O
62	R CHIP	HR590~591	HRFT103JBA	1/10 10K OHM J 1608	O	O
63	R CHIP	HR592	HRFT472JBA	1/10 4.7K OHM J 1608	O	O
64	R CHIP	HR597	HRFT105JBA	1/10 1M OHM J 1608	O	O
65	R CHIP	HR604	HRFT750JBA	1/10 75 OHM J 1608	O	O
66	R CHIP	HR606	HRFT750JBA	1/10 75 OHM J 1608	O	O
67	R CHIP	HR607	HRFT102JBA	1/10 1K OHM J 1608	O	O
68	R CHIP	HR608	HRFT101JBA	1/10 100 OHM J 1608	O	O
69	R CHIP	HR609	HRFT201JBA	1/10 200 OHM J 1608	O	O
70	COIL CHIP	HR610	HLC479J03A	4.7UH CHIP 2012	O	O
71	R CHIP	HR611	HRFT000JBA	1/10 0 OHM J 1608	O	O
72	R CHIP	HR612	HRFT330JBA	1/10 33 OHM J 1608	O	O
73	R CHIP	HR613	HRFT750JBA	1/10 75 OHM J 1608	O	O
74	R CHIP	HR614	HRFT330JBA	1/10 33 OHM J 1608	O	O
75	COIL CHIP	HR616	HLC479J03A	4.7UH CHIP 2012	O	O
76	R CHIP	HR617~621	HRFT301JBA	1/10 300 OHM J 1609	O	O
77	R CHIP	HR622~623	HRFT330JBA	1/10 33 OHM J 1608	O	O
78	R CHIP	HR624~625	HRFT101JBA	1/10 100 OHM J 1608	O	O
79	R CHIP	HR626	HRFT402FBA	1/10 4.0K OHM F 1608(1%)	O	O
80	R CHIP	HR630~632	HRFT301JBA	1/10 300 OHM J 1609	O	O
81	R CHIP	HR637	HRFT301JBA	1/10 300 OHM J 1609	O	O
82	R CHIP	HR638~643	HRFT000JBA	1/10 0 OHM J 1608	O	O
83	R CHIP	HR644~646	HRFT104JBA	1/10 100K OHM J 1608	O	O
84	IC MPEG DEC	IC501	1ES4408FD-	ESS4408FD (MPEG DEC)	O	O
85	IC SDRAM	IC502~503	1HY57V1616	HY57V1616	O	O
86	IC FLASHROM	IC505	1M29F080A-	STM29F080A	O	O
87	IC	IC506	1M24C04MN-	M24C04MN S0P	O	O
88	IC VIDEO ENCODER	IC507	1CS4955---	CS4955	O	O
89	IC REGULATOR	IC509	1A1C1117CY	AIC117-CY	O	O
90	IC	IC517	174HCU04--	74HCU04 (INVERTER)	O	O
91	COIL CHIP	L501~502	HLC104J01A	BEAD 120 OHM 100MHZ 2012	O	O
92	COIL CHIP	L503	HLC479J03A	4.7UH CHIP 2012	O	O
93	COIL CHIP	L505	HLC104J01A	BEAD 120 OHM 100MHZ 2012	O	O
94	R CHIP	L506	HRFT561JBA	1/10 560 OHM J 1608	O	O

15. Electrical Parts List

DHC-XD350

NO	PART-NAME	LOCATION	PART-CODE	PART-DESC	XD300	XD350
95	COIL CHIP	L508	HLC479J03A	4.7UH CHIP 2012	O	O
96	R CHIP	L509~510	HRFT561JBA	1/10 560 OHM J 1608	O	O
97	R CHIP	L511	HRFT331JBA	1/10 330 OHM J 1608	O	O
98	R CHIP	L512~513	HRFT561JBA	1/10 560 OHM J 1608	O	O
99	COIL CHIP	L602~604	HLC829J03A	8.2UH	O	O
100	CONN FFC	WC500	9728816200	FFC 8P P=1.0X220MM R	O	O
101	CONN FFC	WC501	9728816300	FFC 11P P=1.0X220MM R	O	O
102	CRYSTAL QUARTZ	XC501	5XE27M000J	27MHZ HC-49/U (RADIAL/SMD)	O	O
1	PCB REG AS	13000	9CDC061100	DV-215	O	O
2	PCB REG	B901	9CD6586700	80X130	O	O
3	C CERA	CC901~905	CCXF1H473Z	50V F 0.047MF Z (TAPPING)	O	O
4	C ELECTRO	CE901	CEXF1C102V	16V RSS 1000MF (10X20) TP	O	O
5	C ELECTRO	CE902	CEXF1E101V	25V RSS 100MF (6.3X11) TP	O	O
6	C ELECTRO	CE905	CEXF1C472C	RUS 16V 4700MF 16X35.5	O	O
7	C ELECTRO	CE906	CEXF1C471V	16V RSS 470MF (8X12)TP	O	O
8	C ELECTRO	CE907	CEXF1C222V	16V RSS 2200MF (16X31.5) TP	O	O
9	C ELECTRO	CE908	CEXF1E221V	25V RSS 220MF (8X11.5) TP	O	O
10	C ELECTRO	CE909~910	CEXF1E102V	25V RSS 1000MF (13X20) TP	O	O
11	C ELECTRO	CE911~912	CEXF1E101V	25V RSS 100MF (6.3X11) TP	O	O
12	C ELECTRO	CE913~918	CEXF1H470V	50V RSS 47MF (6.3X11) TP	O	O
13	C ELECTRO	CE919~920	CEXF1H109V	50V RSS 1MF (5X11) TP	O	O
14	C ELECTRO	CE921	CEXF1C472C	RUS 16V 4700MF 16X35.5	O	O
15	C ELECTRO	CE922	CEXF1C102V	16V RSS 1000MF (10X20) TP	O	O
16	C ELECTRO	CE923	CEXF1E470V	25V RSS 47MF (5X11) TP	O	O
17	C MYLAR	CM904~906	CMXM2A473J	100V 0.047MF J (TP)	O	O
18	C MYLAR	CM907~912	CMXM2A223J	100V 0.022MF J TP	O	O
19	CONN AS	CN903	9728815300	#22 3P-4P P=2.0, 5.0 200MM	O	O
20	CONN AS	CN907	9728814600	#22 4P P=2.0 200MM	O	O
21	CONN AS	CN993	9728814900	#22 6P P=2.0 150MM	O	O
22	CONN WAFER	CW901	9728808400	VH-2A WAFER	O	O
23	CONN WAFER	CW902	9728815500	WAFER P=2.5 (TJC307A)	O	O
24	CONN AS	CW903	9728814300	#26 8P PITCH 2.0 200MM BOARD IN	O	O
25	CONN AS	CW904	9728815200	#22 5P P=2.5 BOARD-IN 350MM	O	O
26	DIODE	D901~904	D1N4007---	IN4007	O	O
27	DIODE	D905	DZN4148---	1N4148 AUTO 52MM	O	O
28	DIODE	D906~916	D1N4007---	IN4007	O	O
29	DIODE	DB902	DKBPC806--	KBPC806	O	O
30	DIODE BRIDGE	DB903~904	D2W10L----	2W10L	O	O
31	DIODE ZENER	DZ901	DZTZ3R3B--	MTZ 3.3V B	O	O
32	DIODE ZENER	DZ902	DZTZ4R3B--	MTZ4.3B	O	O
33	DIODE ZENER	DZ903	DZTZ30B---	MTZ30B	O	O
34	TERMINAL GND	G981	9CD6450500	SNP 0.3T	O	O
35	IC REGULATOR	IC901~902	1K1A7805AP	K1A7805AP	O	O
36	IC	IC903	1KA378R05-	KA378R05	O	O
37	IC REGULATOR	IC904	1K1A7805AP	K1A7805AP	O	O
38	IC REGULATOR	IC905	1K1A7812AP	K1A7812AP	O	O
39	IC	IC906	1K1A7912AP	KIA7912AP (MOLD)	O	O
40	WIRE JUMPER	JW901~904	W581GY7595	AWG22 1/0.65 SN 7.5 AUTO	O	O
41	WIRE JUMPER	JW905	W581GY6095	AWG22 1/0.65 SN 6 AUTO	O	O
42	TR	Q901	TKRC107M--	KRC 107-M (TAPPING)	O	O
43	TRANSISTOR	Q902	TZTC3198Y-	KTC3198Y-(1815Y) (AUTO)	O	O
44	TR	Q903	TZTA1273Y-	KTA1273Y(966Y)	O	O

NO	PART-NAME	LOCATION	PART-CODE	PART-DESC	XD300	XD350
45	R CARBON FILM	R901	RD-4Z101J-	1/4 100 OHM J	O	O
46	R CARBON FILM	R903~904	RD-AZ472J-	1/6 4.7K OHM J	O	O
47	R CARBON FILM	R905	RD-AZ221J-	1/6 220 OHM J	O	O
48	R CARBON FILM	R906	RD-AZ223J-	1/6 22K OHM J	O	O
49	R CARBON FILM	R907	RD-4Z100J-	1/4 10 OHM J	O	O
50	R CARBON FILM	R908	RD-AZ332J-	1/6 3.3K OHM J	O	O
51	R CARBON FILM	R909	RD-AZ103J-	1/6 10K OHM J	O	O
52	R M-OXIDE FILM	R916~925	RS-4Z478J-	1/4 0.47 OHM J	O	O
1	PCB STANDBY AS	15000	9CDC061300	DV-215	O	O
2	CORD AC	AC991	9736908600	KE-25 H03VVH2-F 1820MM	O	O
3	PCB STANDBY	B981	9CD6586900	139X98	O	O
4	C CERA AC	CC982	CH1BFE472M	AC400V 4700PF M U/C/V	O	O
5	CONN AS	CN984	9728815200	#22 5P P=2.5 BOARD-IN 350MM	O	O
6	CONN WAFER	CW981	9728808100	GP390-03P-TS-M(W/O CENTER	O	O
7	CONN WAFER	CW982	9728815600	WAFER P=7.92 (VH792-03A WHIT	O	O
8	DIODE	D981	D1N4007---	IN4007	O	O
9	FUSE GLASS TUBE	F981	5FSGB2022L	SEMKO TL 2A 250V MF51	O	O
10	HOLDER FUSE CLIP	FC981~982	9734600800	PI5.2 - REEL	O	O
11	TRANS POWER SUB	PT981	5TP8028875	EI=28X12 230V 50HZ	O	O
12	TRANS POWER MAIN	PT991	5TP8066876	EI=66X80 230V 50HZ	O	O
13	SW RELAY	RY981	5SC2001A01	SDT-S-105LMR	O	O